

ATTENTION ALL USERS PAGE (AAUP)

CONTINUED FROM PREVIOUS PAGE

EXPANDED PROCEDURES (Optional, brief if necessary)

1. **ATIS.** When the ATIS broadcast advises that simultaneous ILS PRM approaches are in progress, pilots should brief to fly the ILS PRM approach. If later advised to expect an ILS approach, the ILS PRM chart may be used after noting the following:

- (a) Minimums and missed approach procedures are unchanged.
- (b) Monitor frequency no longer required.
- (c) A lower glideslope intercept altitude may be assigned when advised to expect an ILS approach.

2. **Dual VHF Communication required.** To avoid blocked transmissions, each runway will have two frequencies, a primary and a PRM monitor frequency. The tower controller will transmit on both frequencies. The PRM Monitor controller's transmissions, if needed, will override both frequencies. Pilots will ONLY transmit on the tower controller's frequency, but will listen to both frequencies. When practical, on a second communications radio, select the PRM monitor frequency. Set the audio level to about the same volume as the primary communication radio so that transmissions on the PRM monitor frequency can be heard in the event the tower frequency is blocked. Then, deselect the PRM monitor audio. When instructed by ATC to contact the tower, reselect the PRM monitor frequency audio.

3. All **"Breakouts" are to be hand flown** to assure that the maneuver is accomplished in the shortest amount of time. Pilots, when directed by ATC to break off an approach, must assume that an aircraft is blundering toward their course and a breakout must be initiated immediately.

- (a) **ATC Directed "Breakouts":** ATC directed breakouts will consist of a turn and a climb or descent. Pilots must always initiate the breakout in response to an air traffic controller instruction. Controllers will give a descending breakout only when there are no other reasonable options available, but in no case will the descent be below minimum vectoring altitude (MVA) which provides at least 1,000 feet required obstruction clearance.

- (b) **Phraseology - "TRAFFIC ALERT":** If an aircraft enters the "NO TRANSGRESSION ZONE (NTZ)," the controller will breakout the threatened aircraft on the adjacent approach. The phraseology for the breakout will be:

"TRAFFIC ALERT, (aircraft call sign) TURN (left/right) IMMEDIATELY, HEADING (degrees), CLIMB/DESCEND AND MAINTAIN (altitude)".

EC-1, 26 JUN 2014 to 24 JUL 2014

EC-1, 26 JUN 2014 to 24 JUL 2014