


AIRPORT DIAGRAM

ATIS 281.0
 NAVY JACKSONVILLE TOWER ★
 120.0 340.2
 GND CON
 128.6 336.4
 CLNC DEL
 134.775 (CTAF) 353.675

30° 15' N

MAY 2014
 ANNUAL RATE OF CHANGE
 0.1° W



ELEV 13

CALA

NORTH-SOUTH REF LINE

FLYING CLUB

COMPASS ROSE

FIRE STATION

FIELD ELEV 20

30° 14' N

095.8°

E-28

E-28

8002 x 200

E-28

275.8°

ELEV 9

28

1000 x 100

A

E

511

VP-30 HANGAR

HOT REFUEL PITS

D

C

P-3 WASHRACK

HANGAR 1000

A

A

WASHRACK

113

114

115

116

HANGARS

1002

117

279

PAX TRML

1122

124

140

180 WATER TOWER

H

6

5

4

3

1

H

1

H

3

1

H

1

H

1

H

1

H

ELEV 15

CONTROL TOWER/
BASE OPS

HELO WASHRACK

ELEV 10

3

1

H

1

H

1

H

1

H

1

H

1

H

1

H

1

H

1

H

1

H

1

H

1

H

1

H

1

H

1

H

30° 13' N

81° 41' W

Rwy 10-28
 PCN 30 R/C/W/T
 Rwy 14-32
 PCN 30 F/B/W/T
 Rwy 14 Idg 3241'

81° 40' W

AIRPORT DIAGRAM

SE-3, 26 JUN 2014 to 24 JUL 2014

SE-3, 26 JUN 2014 to 24 JUL 2014