

AIRPORT DIAGRAM

AL-5165 (FAA)

SPRINGDALE MUNI (ASG)
SPRINGDALE, ARKANSAS

AWOS-3
124.675
SPRINGDALE TOWER ★
118.2
GND CON
121.6

94°07.5'W

94°07.0'W

FIELD
ELEV
1353

36°11.0'N

36°10.5'N

36°10.0'N

81 ELEV
1339

A1

A2

A3

A4

A5

A6

A

A

A

A

A

A

A

A

B1

B2

B3

B4

B5

B

B

B

B

B

B

B

B

B

HAZARDOUS
CARGO

185.8°

VAR 1.3° E

JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

TWR
1436

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

TERMINAL

5302 X 76

005.8°

36

RWY 18-36
S-35, D-50, 2D-90
ELEV
1352

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

SC-1, 25 FEB 2021 to 25 MAR 2021

SC-1, 25 FEB 2021 to 25 MAR 2021

AIRPORT DIAGRAM

SPRINGDALE, ARKANSAS
SPRINGDALE MUNI (ASG)